



**Free Questions for H12-425\_V2.0 by dumpssheet**

**Shared by Mckenzie on 15-04-2024**

**For More Free Questions and Preparation Resources**

**Check the Links on Last Page**

## Question 1

---

**Question Type:** MultipleChoice

---

After the Power Echo is installed, the default user name is admin. The password is changed upon the first login. If the password is forgotten, it can be retrieved and reset through project verification.

**Options:**

---

A- True

B- False

**Answer:**

---

A

## Question 2

---

**Question Type:** MultipleChoice

---

If the UPS5000-E is overloaded in normal mode, it transfers to bypass mode immediately. The bypass supplies power to loads to protect the UPS.

**Options:**

---

A- True

B- False

**Answer:**

---

B

## Question 3

---

**Question Type: MultipleChoice**

---

A data center is at the Tier IV level and uses Huawei FusionModule2000 smart module. In this smart module, the PDU8000 integrated PDF cannot be used to supply power to IT loads and precision air conditioners at the same time because isolation requirements are not met.

**Options:**

---

**A-** True

**B-** False

**Answer:**

---

B

## Question 4

---

**Question Type:** MultipleChoice

---

To modify the FusionModule2000 plan view of the ECC800-Pro, users need to log in to the WebUI as admin account.

**Options:**

---

**A-** True

**B-** False

**Answer:**

---

A

## Question 5

---

**Question Type:** MultipleChoice

---

If multiple SmartLi battery cabinets are combined, press and hold the POWER ON/OFF button on each battery management module for more than 2s, and then switch on the battery circuit breaker in any cabinet to start all battery cabinets.

**Options:**

---

**A-** True

**B-** False

**Answer:**

---

A

## Question 6

---

**Question Type:** MultipleChoice

---

The optional temperature and humidity sensor for the UP55000 cannot be cascaded.

**Options:**

---

**A-** True

**B-** False

**Answer:**

---

B

## Question 7

---

**Question Type:** MultipleChoice

---

After all historical alarms of the NetCol5000-A are deleted, the deletion operation is not logged.

**Options:**

---

A- True

B- False

**Answer:**

---

B

## Question 8

---

**Question Type: MultipleChoice**

---

For FusionModule2000, depending on different layout position, batteries can be deployed in the smart module or out of the smart module.

**Options:**

---

A- True

B- False

**Answer:**

---

A

## Question 9

---

**Question Type:** MultipleChoice

---

In the water-side free cooling solution, cold water cannot be transported directly from the cooling tower to chilled conditioner?

**Options:**

---

**A-** True

**B-** False

**Answer:**

---

A

## Question 10

---

**Question Type:** MultipleChoice

---



The ECC800-Pro is the core component for FusionModule2000 local management. Southbound components can be using the PoE bus.

**Options:**

---

**A-** True

**B-** False

**Answer:**

---

A

## Question 11

---

**Question Type:** MultipleChoice

---

Smart ETH gateways cannot be cascaded.

**Options:**

---

**A-** True

**B-** False

**Answer:**

---

B

**To Get Premium Files for H12-425\_V2.0 Visit**

**[https://www.p2pexams.com/products/h12-425\\_v2.0](https://www.p2pexams.com/products/h12-425_v2.0)**

**For More Free Questions Visit**

**<https://www.p2pexams.com/huawei/pdf/h12-425-v2.0>**

